



Installation Instructions Front Bar Part # 6042
98-02 TROOPER ISUZU TROOPER/98-00 ACURA SLX

Parts List

- 1 – Front bar
- 2 – Frame mounting brackets
- 6 – 7/16 x 1 ¼ Hex bolts
- 2 – 7/16 X 3-1/4 Hex bolts
- 8 – 7/16 Hex nuts
- 14 – 7/16 Flat washers
- 2- #10 x 30 mm Hex bolts

Installing the frame mounting brackets

1. Remove factory passenger tow hook from the front section of vehicle; (temporarily to install frame brackets).
2. Using the 10 x 30 mm hex bolts, and 7/16 x 3 ¼ hex bolts attach the driver mounting brackets as per diagram below (do not fasten these bolts to tight as you may have to move the brackets around slightly to align the front bar to bumper. Attach the passenger side mounting brackets using the existing bolts, and tow hook.
3. With the help of another person, align the front bar to the mounting frame brackets, and fasten using the 7/16 x 1 ¼” hex bolts, 7/16 hex nuts and 7/16 flat washers.
4. Align the front bar to the brackets inner edge using 7/16 hardware and proceed to tighten all fasteners.

Note: It is advisable to re-check all fasteners for tightness periodically (every month)

DRIVER SIDE SHOWN

