



INSTALLATION INSTRUCTIONS

GRILL/ BRUSH GUARD 5044

99-00 DODGE SPORT P/U FULLSIZE 2/4WD

PARTS LIST

- | | |
|------------------------------|-------------------------|
| (1) FRONT BAR | (16) 7/16" FLAT WASHERS |
| (2) FRAME MOUNT BRACKETS | (8) 7/16" HEX LOCK NUTS |
| (2) BRACE BRACKETS | (2) 3/8 BUTTON BOLTS |
| (8) 7/16" x 1 1/2" HEX BOLTS | (4) 3/8 NYLON LOCK NUTS |
| (2) 3/8 FLAT WASHERS | |

PROCEDURE

INSTALLING THE MOUNT BRACKETS

1. Remove factory tow hooks from front section of vehicle (if so equipped).
2. Using bolts that held tow hooks in place, attach the mounting frame brackets facing inward (leave semi loose as you may have to align front bar later).
3. Attach top support bracket to the existing holes located on the inner vent bumper opening using the 7/16 x 1 1/2 bolts and hardware.

INSTALLING THE FRONT BAR

4. Line up the 3 holes on the lower portion of the Front Bar with the 3 holes of the Frame Mount Brackets and attach using (3) 7/16" x 1 1/4" hex bolts, (6) 7/16" flat washers, and (3) 7/16" hex lock nuts for each side. The mounting brackets also line up the one hole on the center portion of the front bar with the one hole on the top mounting brackets outer edge. Use the 3/8 hardware to fasten.
5. Align front bar assembly with front of the vehicle and secure all fasteners.

SEE ILLUSTRATION BELOW

