



ARIES AUTOMOTIVE SECURITY BOX INSTALLATION PART #100, 110, 111

Parts included:

1. Security Box
2. Universal Carbon Sleeve
3. 2 Keys
4. 4 -#12 -1.25" self tapping screws

-
1. Make sure all contents are within package.
 2. Check key with lock before mounting, and remove box from sleeve.
 3. Find a level area to mount sleeve. The sleeve can be mounted either vertical or horizontal. This mount area should screw into something solid. Note, it is important before mounting to make sure you leave adequate room to slide box out and in. **See image 1.**
 4. Use the 4- #12 self tapping screws to mount sleeve into secure area. It is important to use all mount holes and screws so that sleeve sits secure and flush.
 5. Once mounted the Security Box is ready for use.

FIGURE 1



NOTES:

- The Security Box locks into place automatically when slide completely into sleeve. It is still important to check each time the box is in sleeve.
- Follow the open/close instructions outside the box.