

INSTALLATION INSTRUCTIONS

4" OVAL

00-07 SILVERADO CREW CAB 1500/00-06 SUBURBAN

PART NUMBER 224013/224013-2

PARTS LIST:

1	Passenger Side Bar	1	Back Passenger Side Bracket (e)
1	Driver Side Bar	1	Back Driver Side Bracket (f)
1	Front Passenger Side Mounting Bracket (a)		
1	Front Driver Side Mounting Bracket (b)	12	8-12.25MM x 20MM
1	Center Passenger Side Bracket (c)	12	8MM Lock Washers
1	Center Driver Side Bracket (d)	2	8MM Flat Washers

PROCEDURE:

1. REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY.
2. Remove existing 12MM body mount bolts from underside of cab. Do not discard!
3. Install brackets using existing 12MM Body Mount Bolts. Mount in direction as shown in photo.
4. Line bracket holes with those of the oval tube. Assemble 8MM hardware.
5. Make sure step bar and brackets are properly aligned.



Figure 1

FINISH PROTECTION- ARIES PRODUCTS HAVE A HIGH FINISH THAT MUST BE MAINTAINED SUCH AS ANY OTHER HIGH FINISH PRODUCT ON THE VEHICLE. PROTECT THE FINISH WITH A NON-ABRASIVE AUTOMOTIVE WAX. THE USE OF SOAP, POLISH, OR WAX THAT CONTAINS ABRASIVES IS DETRIMENTAL, AS THE COMPOUNDS SCRATCH THE FINISH AND OPEN IT TO CORROSION.

DISCLAIMER- BUYER ASSUMES ALL RISK AND LIABILITY WHATSOEVER FROM THE INSTALLATION AND USE OF ARIES PRODUCTS. ARIES PRODUCTS ARE SOLD AS DECORATIVE ACCESSORIES AND SHOULD NOT BE RELIED UPON AS PROTECTION FOR THE VEHICLE OR OCCUPANTS IN THE EVENT OF A COLLISION OR ROLL OVER. ARIES AUTOMOTIVE ASSUMES NO LIABILITY FOR INJURY, LOSS, INCIDENTAL OR CONSEQUENTIAL DAMAGES IN THE EVENT OF A COLLISION OR ROLLOVER