



INSTALLATION INSTRUCTIONS

SIDE BAR PART #206005/206005-2
2005 Honda Ridgeline

PARTS LIST

- | | |
|----------------------------------|---------------------------|
| (1) SIDE PASSENGER SIDEBAR | (20) M8 X 25mm HEX BOLTS |
| (1) DRIVER SIDEBAR | (20) M8 FLAT WASHERS |
| (1) PASSENGER SIDE FRONT BRACKET | (20) M8 LOCK WASHERS |
| (1) PASSENGER MIDDLE BRACKET | (12) M10 X 25mm HEX BOLTS |
| (1) PASSENGER REAR BRACKET | (12) M10 FLAT WASHERS |
| (1) DRIVER SIDE FRONT BRACKET | (12) M10 LOCK WASHERS |
| (1) DRIVER SIDE MIDDLE BRACKET | |
| (1) DRIVER SIDE REAR BRACKET | |

PROCEDURE

1. Begin installation by working on driver side of the vehicle (refer to Figure 1)
2. Locate existing holes under vehicle. These will have plastic tabs in place, so remove to get to existing holes needed. Install Mount Brackets with M8 x 25MM hex bolts and hardware. Leave semi loose for adjustment.
3. Fasten side tube to mount brackets using M10 x 25MM hex bolts and hardware. Hand tighten side tube to all three brackets.
4. Tighten down body mount bolts.
5. Repeat process for passenger side of vehicle to complete installation

Figure 1

