



INSTALLATION INSTRUCTIONS

TAILLIGHT GUARD PART #T7760 96-03 NISSAN PATHFINDER

PARTS LIST

- (1) TAILLIGHT GUARD PASSENGER SIDE
- (1) TAILLIGHT GUARD DRIVER SIDE
- (4) M6-1.0*25MM

PROCEDURE

- 1) THERE ARE PASSENGER AND DRIVER SIDE TAIL LIGHT GUARDS. OPEN REAR HATCH, REMOVE UPPER AND LOWER SCREWS IN TAIL LIGHT ASSEMBLY. DISCARD FACTORY SCREWS.
- 2) POSITION APPROPRIATE TAIL LIGHT GUARD ON TAIL LIGHT, ALIGNING WITH THE M6*25MM SCREWS ON LIGHT ASSEMBLY AND TAIL LIGHT GUARD BRACKETS TO ATTACH TO VEHICLE.
- 3) REPEAT PROCEDURE ON OPPOSITE SIDE. INSTALLATION IS COMPLETE.

NOTE THIS TAIL LIGHT GUARD WAS DESIGNED TO FIT SNUGLY AGAINST THE BODY OF YOUR FORD EXPLORER. AS THE SCREWS ARE TIGHTENED THE TAIL LIGHT GUARD WILL DRAW IN TO BODY TO PROVIDE A TIGHT FIT. IF YOU FEEL THE GUARD IS TOO TIGHT WHERE THE RUBBER MEETS THE BODY. YOU CAN SLIGHTLY BEND THE MOUNTING BRACKETS TO LESSEN THE PRESSURE ON THE BODY.

CUSTOMER SERVICE/TECH. HELP – TOOL FREE (888) 800-ARIES