



INSTALLATION INSTRUCTIONS

TAILLIGHT GUARD PART #T4468-2/T4468 2003-07 TOYOTA 4RUNNER

PARTS LIST

- (1) TAILLIGHT GUARD PASSENGER SIDE
- (1) TAILLIGHT GUARD DRIVER SIDE
- (4) #14 X 1" SCREWS

PROCEDURE

- 1) START WITH THE PASSENGER SIDE, OPEN THE REAR DOOR AND REMOVE THE PLASTIC COVER PANEL THAT IS INSIDE THE VEHICLE TO GIVE YOU ACCESS TO THE HEX NUTS THAT HOLD THE TAIL LIGHT HOUSING. REMOVE THE HEX NUTS HOLDING THE TAIL LIGHT HOUSING AND SLIGHTLY PULL OUT THE TAIL LIGHT HOUSING JUST ENOUGH TO SLIDE THE TAIL LIGHT GUARD OVER IT.
- 2) ONCE TAIL LIGHT GUARD IS FITTED ON THE TAIL LIGHT HOUSING. MAKE SURE THAT THE SUPPORT BRACKETS HOOK TO THE EDGE OF THE TAIL LIGHT HOUSING AND HAND TIGHTEN ASSEMBLY BACK TO VEHICLE. MAKE SURE THAT THE INNER BRACKET FALLS ON THE DOOR JAMB PLASTIC MOLDING.
- 3) WHILE HOLDING IN POSITION, SLOWLY AND CAREFULLY CLOSE HATCH TO MAKE SURE THERE IS ADEQUATE CLEARANCE FOR REAR HATCH TO OPERATE WITHOUT TOUCHING TAIL LIGHT GUARD. ONCE ADEQUATE CLEARANCE IS ACHIEVED. MARK LOCATION OF HOLES IN BRACKET ONTO JAMB.
- 4) DRILL. WHERE MARKED USING A (1/8") DRILL BIT. ATTACH TAIL LIGHT GUARD USING THE SCREWS PROVIDED. TIGHTEN HEX NUT AND REINSTALL PLASTIC COVER.
- 5) REPEAT STEPS 1—4 TO INSTALL OPPOSITE SIDE TAIL LIGHT GUARD.

CUSTOMER SERVICE

TOLL FREE (888) 800-ARIES